



Senstar Symphony Server  
8.7.x  
Release Notes



# Contents

---

Information..... 3

Release 8.7.0 (May 2024)..... 4

Legal information..... 11

## Information


---



**Note:** Senstar does not support connecting the Senstar Symphony Client 8.x to the Senstar Symphony Server 7.x and cannot guarantee that all functionality will work as expected.

# Release 8.7.0 (May 2024)

## New features

Issue ID	Description
AIR-47754	<p>The Senstar Symphony Client includes a new video player based on the GStreamer framework.</p> <p>The new video player is turned off by default. To preview the new video player in the Senstar Symphony Client interface, select a view panel, hold the CTRL key, and click a camera in the device tree.</p>
AIR-47959	<p>The Senstar Symphony Server supports ONVIF Profile M for cameras with the Object Detection and Tracking (Profile M) add-on.</p>
AIR-48451	<p>The Senstar Symphony AI Object Detection and Tracking video analytic includes new decorations and an optional confidence decoration.</p>
AIR-49111	<p>The Senstar Symphony Server supports the integration of Salto access control systems.</p>
AIR-49164	<p>You can lock the Senstar Symphony Client and still allow users to search for and export video.</p>
AIR-49534 AIR-49536	<p>The Senstar Symphony Mobile Bridge API includes functionality to retrieve information about and send commands to integrations from the Senstar Symphony Server.</p>
AIR-49565	<p>You can add an HTML page to the instructions associated with an alarm and view the page in a browser window in the alarm console.</p>
AIR-49682	<p>The Senstar Symphony Server supports new scheduled events. You can create a schedule event in the Senstar Symphony Server configuration interface and then use the event to trigger the actions for rules at a specific time of day.</p>
AIR-49689	<p>The maximum width for lines on maps in the Senstar Symphony Client interface has increased to 10 pixels.</p>
AIR-49726	<p>You can change the outline color for labels on maps in the Senstar Symphony Client interface to make the font more visible.</p>
AIR-49727	<p>You can change the font size for the text in the alarm console of the Senstar Symphony Client interface.</p>
AIR-49756	<p>The Senstar Symphony Client includes a new layout engine that is more robust and scalable. When you load saved layouts from a previous version of the Senstar Symphony Client, the Senstar Symphony Client automatically converts those layouts to work with the new layout engine.</p> <p> <b>Note:</b> The new layout is enabled by default, but you can disable the new layout engine and use the old layout engine. Contact Senstar Support for assistance.</p>

Issue ID	Description
VIS-1276	<p>Senstar has introduced three new video analytics:</p> <ul style="list-style-type: none"> <li>• Senstar Symphony AI Object Detection and Tracking</li> <li>• Senstar Symphony AI Overhead People Tracking and Counting</li> <li>• Senstar Symphony AI Thermal Object Detection and Tracking</li> </ul> <p>Although similar, each analytic uses a different DNN model that was built specifically for the video analytic.</p>

## Improvements

Issue ID	Description
AIR-44340	The Reset Alarm option in the advanced alarm console is no longer available for archived alarms.
AIR-44782	The icon in the Senstar Symphony Client that opens the Advanced Alarm Console has been redesigned.
AIR-47380	The context menu item for pasting a view panel in the Senstar Symphony Client interface is now labeled Copy Panel.
AIR-47396	Automatically generated rules for Senstar Network Manager integrations now alarm on a map if there are no cameras added to the Senstar Symphony Server.
AIR-48222	The Senstar Symphony Server can now retrieve the UTC timestamp for the last displayed frame, which improves the accuracy of the timelines in the Senstar Symphony Client interface.
AIR-48785	The Senstar Symphony Client is more efficient at switching between different moments in historical video, switching between historical video and live video, and switching between different cameras; and it does not display video artifacts while switching.
AIR-48869	There is a select all option when you are adding nodes for a Senstar Network Manager integration.
AIR-48893	Clicking on a blank view panel or a view panel that contains a map or browser brings the view panel into focus.
AIR-48957	The same alarm retains focus when you switch between the simple and advanced alarm console.
AIR-49047	The Senstar Symphony Server now supports Windows 11 IoT and the Senstar Symphony Database now supports Microsoft SQL Server 2022.
AIR-49107	The decoration font scales to the size of the view panel.
AIR-49119	When it starts, the Senstar Symphony Client displays the Waiting for event message in blank view panels that are set to switch on alarm. This indicates that the Switch on Alarm functionality is active for the view panel.

Issue ID	Description
AIR-49248	Events from integrations can trigger the Enable with Relay operation for the Senstar Symphony Automatic License Plate Recognition video analytic.
AIR-49265	You can reset a standard two-stage alarm from a map without having to navigate through the alarm details page.
AIR-49343	To improve security and support the new Senstar Symphony Mobile Application, the Senstar Symphony Server conducts more expansive verification of SSL certificates.
AIR-49350	Alarm reports now include zone names or aliases so that you can see which zone triggered the event..
AIR-49351	Alarm reports now include the absolute distance and the relative distance in their own columns.
AIR-49446	The Senstar Symphony Database has been optimized to be more efficient when processing video from edge storage.
AIR-49448	The Cleaner process does not run as scheduled if the Senstar Symphony Database is unresponsive.
AIR-49597	Clicking an alarm does not reload a map or camera if the alarm applies to the same map or camera as the previous alarm.
AIR-49643	The Senstar Symphony Server is more efficient at saving changes to rules for that affect hardware integrations.
AIR-49731	The Senstar Symphony Server sends the entire audio file for audio out functionality.
AIR-49735	The performance of the Senstar Symphony Server has improved when you are modifying rules, events, and actions sets.
AIR-49815	The performance of the Senstar Symphony Server has improved when you create a new rule with a Senstar Symphony Server that already contains a large number of rules.
AIR-49901	The camera IO overlay controls and integration overlay controls appear as expected in the Senstar Symphony Client interface.
AIR-49933	The Senstar Symphony Client interface displays a pop-up window it converts an old layout into a new layout. Additionally, the Senstar Symphony Client interface displays a pop-window asking you to confirm saving the layout in the new layout format.
AIR-50028	The Senstar Symphony logs now include both the matched license plate and the matched license plate pattern.

## Fixes

Issue ID	Description
AIR-40596	The timestamp on the alarm image that the Senstar Symphony Server sends to FTP matches the timestamp on the alarm that generated the image.
AIR-45870	The Reset button appears as expected in the advanced alarm console when you enable two-stage alarms.
AIR-48223	The Toggle State command is consistent across all integrations in the Senstar Symphony Server configuration interface.
AIR-48467	Clicking on the consolidated timeline affects all of the view panels as expected.
AIR-48510	When displaying a camera in a view panel after displaying a map, browser, or carousel in the same view panel, the timeline appears as expected.
AIR-48578	Navigating between bookmarks in the Senstar Symphony Client interface works as expected.
AIR-48582	Video navigation in the Senstar Symphony Client interface works as expected when timelines are turned off.
AIR-48583	Bookmark navigation in the Senstar Symphony Client interface applies only to the bookmarks for cameras open in view panels.
AIR-48597	Video panels synchronize to the selected video panel as expected when you lock the panels in the Senstar Symphony Client interface.
AIR-48601	The consolidated timeline in the Senstar Symphony Client interface updates as expected as a carousel in a view panel progresses through cameras.
AIR-48609	The Senstar Symphony Client does not stop responding if you Export All from the context menu in a view panel.
AIR-48614	You can move to another bookmark as expected if you are already viewing a bookmark in a view panel.
AIR-48621	The Senstar Symphony Client displays the correct video stream when you set the video quality to the lowest resolution.
AIR-48624	The Senstar Symphony Server retains comments that you add to alarms with extended information (for example, extended information from the Senstar Symphony Automatic License Plate Recognition video analytic or Senstar Symphony Face Recognition video analytic).
AIR-48673	Dragging a carousel into a view panel in the Senstar Symphony Client interface does not cause the Senstar Symphony Client to stop responding.
AIR-48676	View panels in the Senstar Symphony Client interface display the proper notification when historical video is not available.
AIR-48701	The device tree in the Senstar Symphony Client interface loads as expected.

Issue ID	Description
AIR-48853	Audio is smoother in historical video from Axis and Bosch cameras.
AIR-48856	The Senstar Symphony Client does not stop responding if you select an alarm on a map in a view panel.
AIR-48906	Alarms that you trigger on a map retain information about the alarm type (for example, access granted or access denied) as expected.
AIR-49108	Areas that you mark for a search appear in the correct location on the image in the search results.
AIR-49129	The camera controls in the Senstar Symphony Client interface render at the proper brightness.
AIR-49175	The log on user is set correctly and the setup wizard finishes successfully during a silent upgrade installation.
AIR-49185	The tooltip for the consolidated timeline in the Senstar Symphony Client interface does not block interactions with the consolidated timeline.
AIR-49186	Pausing historical video in the Senstar Symphony Client interface does not cause the marker on the timeline to move briefly to live video.
AIR-49205	The Senstar Symphony Client does not stop responding when you try to reset alarms in the advanced alarm console.
AIR-49216	The consolidated timeline is not disabled after you switch panels in the Senstar Symphony Client interface.
AIR-49247	When you draw a zone on a map, the lines will snap to the closest point within 5 pixels.
AIR-49256	The highlight box adjusts as expected when you add a view panel after switching a fisheye camera to the quad dewarp mode.
AIR-49273	The consolidated timeline disappears as expected when you add additional cameras to view panels in the Senstar Symphony Client interface without lock times being enabled.
AIR-49421	The Senstar Symphony Server setup wizard does not stop responding at the Checking Service Accounts step with the AI Infoservice service becoming unresponsive.
AIR-49452	The alarm report displays alarm comments made in Arabic and Hebrew as expected.
AIR-49492	The Senstar Symphony Client does not stop responding when you open the advanced alarm console.
AIR-49497	Camera timelines are not missing footage after download footage from the edge storage on the camera.



Issue ID	Description
AIR-49577	The Senstar Symphony Server does not miss alarms from the Senstar Network Manager while it is reconnecting.
AIR-49588	Aggregated alarm groups expand as expected when you click the group in the alarm console.
AIR-49650	The hide global alarm setting works as expected for the global alarm indicators in the basic alarm console.
AIR-49674	After downloading video from edge storage, the AI Tracker service stops gracefully.
AIR-49690	The alarm status filter drop-down list in the advanced alarm console displays the correct filter name after you close and re-open the advanced alarm console.
AIR-49711	Sending a report to csv adds the escape characters as expected so that columns do not overflow into adjacent columns.
AIR-49719	The commands for masking and unmasking events now check user permissions as expected.
AIR-49824	If you link an audio source to a camera, the camera now gives priority to the linked audio source instead of the camera's audio source. Linked audio takes priority in Senstar Symphony Server 8.7.0 and later.
AIR-49850	The cursor on the consolidated timeline in the Senstar Symphony Client interface does not jump when the camera panel is paused.
AIR-49851	When a camera without video is part of synchronized play, the play/pause button accurately reflects the state of the video (playing or paused).

Known issues

Issue ID	Description
AIR-49405	The Senstar Symphony Client does not initially recognize when you exceed the number of cameras (4) supported by the Lock Times On Navigation (Synchronize Panels) feature and does not disable the button. If you click the Lock Times On Navigation button with too many cameras in the Senstar Symphony Client interface, the Senstar Symphony Client fails to lock and only then disables the button.
AIR-49758	When using the new video engine in the Senstar Symphony Client, view panels might seem to be unsynchronized when a camera navigates backwards over a time without video. However, the panels remain synchronized and any navigation actions that you take in a view panel will bring all panels back to the same time.
AIR-50007	Users cannot view live video in the Senstar Symphony Web Client if there is a umlaut in the user name.

Issue ID	Description
VIS-1239	The Senstar Symphony Client 8.7.0 includes a new video player with new decorations. If you enable the new decorations for the new video player, decorations do not appear in the old video player, which is still an option for the Senstar Symphony Client 8.7.0.

## Legal information

---

Copyright © 2024 Senstar Corporation and/or its Licensor(s). All rights reserved.

This material is for informational purposes only. Senstar makes no warranties, express, implied or statutory, as to the information in this document.

Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Senstar Corporation.

Senstar may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from Senstar, the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

Senstar and the Senstar logo are registered trademarks of Senstar Corporation.

All other trademarks are the property of their respective owners.